

AJ-RC10G Software Confirmation

1. The AJ-RC10G is connected with the Camera Recorder, and turn on the power.
2. Press the **SW ACTIVE** button to turn the lamp on.
3. Press the **SHUTTER/SYSTEM** button twice to display the **SYSTEM MENU** screen on the LCD panel (**SYSTEM lamp** is on).
4. Press the **▼** button several times to display the item "**VERSION**" and confirm that the version number.

VERSION 1.00-00-0.01

5. If the version is the latest one which is shown in "Support Desk", there is no need to update.
6. Press the **SHUTTER/SYSTEM** button and exit from **SYSTEM MENU**.

< CONNECTION >

NOTE: Please use 10-pin cable (10m) attached to AJ-RC10G.

